LOW LIGHT ENHANCEMENT


Eduardo Guiraud - s220501

Muhammad Shaian Latif — s205080

HISTOGRAM EQUALISATION WITH ILUMINATION ADJUSTMENT

- 1. Transform image from RGB to HSV
- 2. Make a histogram equalisation of the Value channel
- 3. Detect the type of low light image
- 4. Adjust the histogram equalisation with a gamma-correction
- 5. Replace the Value channel with the adjusted illumination
- 6. Transform image back to RGB

HISTOGRAM EQUALISATION WITH ILUMINATION ADJUSTMENT





BI-HISTOGRAM EQUALISATION WITH BBHE AND BPHEME

- 1. Transform image from RGB to HSV
- 2. Find the mean value of the Value channel and divide the histogram
- 3. Do the histogram equalisation seperately for histogram higher and lower than the mean value (BBHE)
- 4. Find the peak value of the Value channel and divide the histogram
- 5. Do the histogram equalisation seperately for histogram higher and lower than the peak value (BPHEME)
- 6. Copy the image and replace the Value channel on each with the BBHE and BPHEME
- 7. Transform images back to RGB
- 8. Apply weights on the images and assemble them

BI-HISTOGRAM EQUALISATION WITH BBHE AND BPHEME



RETINEX APPROACH


Preprocessing steps, quite simple

```
# functions
def get_ksize(sigma):
    ksize = int(round((sigma - 0.35)/0.15))
    return ksize


def get_gaussian_blur(img, ksize=0, sigma=5):
    if ksize == 0:
        ksize = get_ksize(sigma)

# Ensure ksize is odd to meet OpenCV's requirement
    ksize = ksize if ksize % 2 != 0 else ksize + 1

return cv2.GaussianBlur(img, (ksize, ksize), sigma)
```



SINGLE SCALE RETINEX (SSR)



SSR - CODE

$$SSR_i(x,y) = \log(I_i(x,y)) - \log(G_\sigma * I_i)(x,y))$$

```
def ssr(img, sigma):
    # Normalize the image to the range [0, 1] and convert to float32 for precision.
    img = img.astype('float32') / 255


# Apply Gaussian blur to the image.
    blurred = get_gaussian_blur(img, sigma=sigma)

# Compute the SSR by taking the logarithmic difference.
    ssr_image= np.log10(img + le-6) - np.log10(blurred + le-6)

return ssr_image
```

MULTI SCALE RETINEX (MSR)





MSR - CODE

$$MSR_i(x,y) = \sum_{n=1}^N w_n SSR_i(x,y)$$

```
def msr(image, sigma_scales=[15, 125, 250]):


# Initialize an accumulator image with the same shape and type as the input image
accumulator = np.zeros_like(image, dtype=np.float32)

# Accumulate SSR (Single Scale Retinex) processed images for each sigma scale
for sigma in sigma_scales:
    processed_image = ssr(image, sigma)
    accumulator += processed_image.astype(np.float32)

# Average the accumulated images
averaged_image = accumulator / len(sigma_scales)

# Normalize the averaged image to the 0-255 range and convert to 8-bit unsigned integer
msr_img = cv2.normalize(averaged_image, None, 0, 255, cv2.NORM_MINMAX, dtype=cv2.CV_8UC3)
return msr_img
```

MULTI SCALE RETINEX WITH COLOR RESTORATION (MSRCR)



MSRCR - CODE

Color Balance function

```
def color balance(image, low percentile, high percentile):
    # Calculate the number of pixels for the low and high thresholds
    total pixels = image.shape[0] * image.shape[1]
    low threshold count = total pixels * low percentile / 100
    high threshold count = total pixels * (100 - high percentile) / 100
    # Split the image into channels or treat as a single channel for grayscale
    channels = cv2.split(image) if len(image.shape) == 3 else [image]
    adjusted channels = []
    for channel in channels:
        # Calculate the cumulative histogram
        channel hist = cv2.calcHist([channel], [0], None, [256], [0, 256])
        cum hist = np.cumsum(channel hist)
        # Determine the intensity values for the specified percentiles
        lower bound, upper bound = np.searchsorted(cum hist, [low threshold count, high threshold count])
        # Create a lookup table to adjust pixel values
        lookup table = np.interp(np.arange(256), [0, lower bound, upper bound, 255], [0, 0, 255, 255]).astype('uint8')
        # Apply the lookup table to adjust the channel
        adjusted channel = cv2.LUT(channel, lookup table)
        adjusted channels.append(adjusted channel)
    # Merge adjusted channels back into an image
    return cv2.merge(adjusted channels) if len(adjusted channels) > 1 else adjusted channels[0]
```

$CRF_i(x,y) = \beta[\log(\alpha*I_i(x,y)) - \log(\sum_{c=0}^{k-1}I_c(x,y))]$

MSRCR - CODE


 $MSRCR_{i}(x, y) = G[MSR_{i}(x, y) * CRF_{i}(x, y) - b]$


```
def msrcr(img, sigma scales=[15, 125, 250], alpha=125, beta=46, G=192, b=-30, low percentile=2, high percentile=1):
   Apply Multi-Scale Retinex with Color Restoration (MSRCR) to an image.
   Parameters:
   - img: Input image as a NumPy array.
   - sigma scales: List of standard deviations for Gaussian blur in MSR.
   - alpha: Gain control for logarithmic nonlinearity in color restoration. (contrast)
   - beta: Offset control for logarithmic nonlinearity in color restoration.(brightness and contrast)
   - G: Gain factor for the final image. (brightness and contrast)
   - b: Offset for the final image. (brightness)
   - low percentile: Lower percentile for color balance. (reduce shadow noise)

    high percentile: Higher percentile for color balance. (prevent clipping)

   Returns:
   - msrcr img: Image after applying MSRCR.
   img = img.astype(np.float64) + 1.0
   # Apply Multi-Scale Retinex (MSR).
   msr img = msr(img, sigma scales)
   # Compute Color Restoration Function (CRF).
   crf = beta * (np.log10(alpha * img) - np.log10(np.sum(img, axis=2, keepdims=True)))
   msrcr imq = G * (msr imq * crf - b)
   msrcr img = cv2.normalize(msrcr img, None, 0, 255, cv2.NORM MINMAX, dtype=cv2.CV 8UC3)
   msrcr img = color balance(msrcr img, low percentile, high percentile)
   return msrcr ima
```

MULTI SCALE RETINEX WITH CHROMACITY PRESERVATION (MSRCP)





MSRCP - CODE

```
def msrcp(img, sigma scales=[15, 125, 250], low percentile=1, high percentile=1):
    # Calculate the intensity image by averaging the color channels.
    intensity image = np.mean(img, axis=2) + 1.0 # Simplified averaging
    # Enhance contrast using Multi-Scale Retinex on the intensity image.
   msr intensity = msr(intensity image, sigma scales)
    # Adjust color balance based on specified percentiles.
    color balanced intensity = color balance(msr intensity, low percentile, high percentile)
    # Compute scaling factor to avoid overflow, adjusted for each pixel.
    scaling factor = 256.0 / (np.max(img, axis=2) + 1.0)
    # Calculate the adjustment ratio for color balancing.
    adjustment ratio = color balanced intensity / intensity image
    # Determine the minimum scaling factor to maintain value range.
    min scaling factor = np.minimum(scaling factor, adjustment ratio)
    # Apply the minimum scaling factor, ensuring pixel values are within [0, 255].
    adjusted img = np.clip(img * min scaling factor[:, :, np.newaxis], 0, 255)
    return adjusted img.astype(np.uint8)
```

Algorithm 2: MSRCP algorithm

```
Data: I input color image; \sigma_1, \sigma_2, \sigma_3 the sca
          side
Result: MSRCP output color image
begin
    Int = (I_R + I_G + I_B)/3
    foreach \sigma_i do
         Diff_i = log(Int) - log(Int * G_{\sigma_i})
     end
    MSR = \sum_{i} \frac{1}{3} Diff_i
    Int_1 = SimplestColorBalance(MSR, s_1, s_2)
    foreach pixel i do
          B = \max(I_R[i], I_G[i], I_B[i])
         A = \min\left(\frac{255}{B}, \frac{\operatorname{Int}_1[i]}{\operatorname{Int}[i]}\right)
         MSRCP_R[i] = A \cdot I_R[i]
         MSRCP_G[i] = A \cdot I_G[i]
         MSRCP_B[i] = A \cdot I_B[i]
    end
end
```

RESULTS

Technique	SSIM	PSNR	ΔE_{94} Average
Illumination Adjustment	0.068899	6.460112	55.907277
BBHE and BPHEME	0.443019	16.391452	12.864055
SSR	0.079659	3.837401	70.582823
MSR	0.079664	3.840461	70.569132
MSRCR	0.116994	10.01133	33.792266
MSRCP	0.136487	10.70646	29.153352

Table 2: Performance Metrics for Image Enhancement Techniques DARK

Technique	SSIM	PSNR	ΔE_{94} Average
Illumination Adjustment	0.385799	8.557906	48.060084
BBHE and BPHEME	0.863048	18.398787	12.025829
SSR	0.219019	3.341695	63.811581
MSR	0.221760	3.533424	62.548926
MSRCR	0.343755	11.46541	32.498825
MSRCP	0.541078	11.90350	29.012738

Table 3: Performance Metrics for Image Enhancement Techniques LIGHT

COLOR DIFFERENCE RESULTS




Illumination adjustment



BBHE and BPHEME

COLOR DIFFERENCE RESULTS



COLOR DIFFERENCE RESULTS



